

INSTALL GUIDE

160MM METRIC COMPRESSION COUPLER



- 1.** Remove bolts and nuts and take two shell halves apart
- 2.** Remove exposed sleeve and O-ring and place on pipe end
- 3.** Push fitting completely home over pipe end
- 4.** Push O-Ring and sleeve into original position
- 5.** Place two shell halves with grip rings inserted over pipe and fitting body. Insert bolts, washers and nuts, then tighten until shells are in contact with each other.