

INSTALL GUIDE

MINE SAFE 63-125MM METRIC COMPRESSION

PLASSON
AUSTRALIA



1.



REMOVE NUT AND PUT GRIP RING ASIDE

PLACE NUT, BUSH AND O-RING ON PIPE TWO DIAMETERS
BACK FROM END

NOTE: USE SILICONE-BASED LUBRICANT ON PIPE AND O-RING

2.



PUSH THE PIPE FULLY ONTO FITTING BODY UP TO END STOP

PUSH THE O-RING AND BUSH UP AGAINST FITTING BODY

**NOTE: THE O-RING AND BUSH WILL NOT ENTER THE
FITTING BODY**

3.



TIGHTEN NUT TO PUSH BUSH AND O-RING INTO FITTING
UNTIL BUSH IS FLUSH WITH FITTING MOUTH

**NOTE: THE GRIP RING IS STILL NOT INSTALLED AT
THIS POINT**

4.



UNDO NUT AND SLIDE BACK ALONG PIPE

INSTALL GRIP RING TO LUGS ARE TOUCHING BUSH

**NOTE: IF REINSTALLING FITTINGS DESTROY OLD GRIP RINGS
AND REPLACE WITH NEW ONES TO ENSURE FIRM BITE**

5.



FIRMLY HAND-TIGHTEN PLUS A 1/2 TURN WITH WRENCHES
MAXIMUM HANDLE LENGTH: 45CM

NOTE: OVER-TIGHTENING NUTS CAN CAUSE BLOWOUTS