

INSTALL GUIDE

UNIVERSAL

ADAPTOR

90° ELBOW



- 1.** Cut and de-burr pipe
- 2.** Slide PLASSON Universal Adaptor fitting end onto pipe up to first resistance point
- 3.** Hand-tighten nut against body and then tighten firmly using PLASSON wrenches
- 4.** Assemble metric PE joint as per standard instructions