

INSTALL GUIDE

UNIVERSAL SLIP REPAIR COUPLER

PLASSON[®]
AUSTRALIA



1



Mark pipe insertion depth

2



Insert the pipe

3



Tighten the nut

JOIN DIFFERENT PIPE MATERIALS FAST

PEX   Galvanised Steel

PE (Portable Water)   Copper

Grey Water   PE (Rural)

CPVC   PVC

PVC   ABS



PLASSON[®]
AUSTRALIA



BEST UNDER PRESSURE | plasson.com.au