



If your control box has not been upgraded free of charge to universal tips, you can use adaptors to connect to fittings with 4.0mm pins. Find your control box in the list, and select the adaptor based on using the control box in SmartFuse or Manual mode.

	Control Box Type	Adaptor for SmartFuse* Applications	Adaptor for Manual** Applications
	SmartFuse 180	Not required. All SmartFuse 180 control boxes are supplied with universal tips	-
	Monomatic	2003004	-
	Polymatic Plus	2003004	2003002
	PolyControl V2	2003004	2003002

\*SmartFuse applications do not require a scanner to read the fitting barcode. Simply connect the red cable to the fitting's red terminal and the black cable to the other terminal and the control box automatically detect the weld time. Press start on the control box to complete the weld.

\*\*Manual applications require the fitting barcode to be scanned. Using these adaptors will not allow the machine to work in SmartFuse mode.






# Special Offer

## Our Adaptor Sale is on now


### For a short time only\*

#### Adaptor for SmartFuse Applications



ADAPTOR	CODE	LIST PRICE	PROMOTIONAL PRICE
Adaptor 4.7 Lead / 4.0 fitting 90Deg angle For use with Plasson SmartFuse and other fittings	2003004	231.34	<b>155.00</b>

#### Adaptor for Manual Applications



ADAPTOR	CODE	LIST PRICE	PROMOTIONAL PRICE
Adaptor 4.7 Lead / 4.0 fitting angle (pair)	2003002	132.30	<b>80.00</b>

\*Our promotional period starts on 02/01/19 and ends on 30/06/19. Standard T&Cs apply.